



HOW TO CHANGE BUTTON OPERATION ON THE SOLO LOOP

The operation of the TALKBACK and PROGRAM buttons can be altered to suit individual requirements. Five combinations are currently available, as described below. The selected configuration will be stored, and reloaded when the GS-SOLO LOOP is next switched on.

To change the operation of the GS-SOLO LOOP:

1. Turn the GS-SOLO LOOP off.
2. Hold down the TALKBACK button.
3. Turn the GS-SOLO LOOP on.
4. Press and release the PROGRAM button n times, where n is the number of the desired configuration, as listed below.
5. Release the TALKBACK button.

The following configuration modes are available:

- 1) **PROGRAM toggle on/off, TALKBACK momentary**
In this configuration, PROGRAM will be suppressed while TALKBACK is held down.
- 2) **PROGRAM toggle on / off (after 5 seconds), TALKBACK momentary**
Same as above, except that the PROGRAM button must be held down for 5 seconds before it will turn off.
- 3) **PROGRAM & TALKBACK toggle on/off separately**
Both PROGRAM & TALKBACK toggle completely independent of each other.
- 4) **PROGRAM & TALKBACK both momentary**
In this configuration, PROGRAM will be suppressed while TALKBACK is held down.
- 5) **PROGRAM cough, TALKBACK momentary**
PROGRAM is normally on, but will be suppressed while either the PROGRAM or TALKBACK buttons are held down.